## SPRAY& **FORGET**

Convenient **HOSE-END SPRAYER** 



WAX

DAMAGE CAUSED BY & BIRD DROPPINGS

**∡** Advanced Water-beading **Technology** 

1 QUART (946mL)

**STEP** 

IMPORTANT: Use only as directed on this label. For outdoor use only. Do not mix with detergents or chemicals. This product can be harmful to fish. Keep product and run off away from ponds, streams, etc.

STORAGE & DISPOSAL: Store in a cool, dry area. Do not refill or reuse this container. Dispose of in accordance with local, state, and federal laws.

DO NOT INGEST.

FIRST AID: EYE EXPOSURE: Rinse cautiously with water for several minutes. Remove contact lenses. present and easy to do. Continue rinsing for several minutes. SKIN EXPOSURE: Wash with plenty of soap an water. IF SWALLOWED: Do not induce vomiting unless directed to do so by medical personnel. Poison Contri Center: 1-800-222-1222.

KEEP OUT OF REACH OF CHILDREN.

Product Category: Instant Detailer • Max. VOC: 0.2% upon dilution





## DIRECTIONS FOR USE:



Begin by washing vehicle with



4. Do not allow RV to dry in direct sunlight before rinsing.



1. Attach garden hose to hose end on 2. Twist spray nozzle for desired product and turn water fully on.

5. Select rinse setting and rinse

thoroughly. No rubbing or buffing





3. Move switch to "CLEAN" position Evenly apply wax over entire RV or camper, starting from top and working down.

This product will not protect against prolonged exposure to pollutants or particulates. Without proper cleaning, foreign substances can damage surfaces. For assistance: Contact us at 1-866-641-0826 in the U.S.A. only

For more ingredient information: Visit www.barringredients.com or call at 1-833-880-5319



SF350 / J9811



©2022 W.M. Barr & Co., Inc. www.sprayandforget.com All rights reserved.



**KEEP OUT OF REACH OF CHILDREN** Read entire label prior to use or storage.